

SAFETY AND BUILDINGS DIVISION
Plumbing Product Review
P.O. Box 2658
Madison, Wisconsin 53701-2658
TTY: Contact Through Relay

Jim Doyle, Governor Richard J. Leinenkugel, Secretary

November 18, 2008

KINETICO INCORPORATED ROD YODER 10845 KINSMAN RD. PO BOX 193 NEWBURY OH 44065

Re: Description: WATER TREATMENT DEVICE-REVERSE OSMOSIS

Manufacturer: KINETICO INCORPORATED

Product Name: KINETICO DRINKING WATER STATION (POU) Model Number(s): K5 USING THE STANDARD TANK (POU)

Product File No: 20080184

The specifications and/or plans for this plumbing product have been reviewed and determined to be in compliance with chapters Comm 82 through 84, Wisconsin Administrative Code, and Chapters 145 and 160, Wisconsin Statutes.

The Department hereby issues an approval based on the Wisconsin Statutes and the Wisconsin Administrative Code. This approval is valid until the end of November 2013. This approval is contingent upon compliance with the following stipulation(s):

- This product has undergone sufficient testing to document the product's ability to reduce only those contaminants and/or substances as specified in this approval letter when the product is installed and maintained in strict accordance with the manufacturers published instructions.
- ➤ Where the Department of Natural Resources (DNR) has jurisdiction, a written approval may be required prior to installation of this product in a water supply system to reduce the concentration of a contaminant that exceeds the primary drinking water standards contained in ch. NR 809, Wis. Admin. Code, the enforcement standards contained in ch. NR 140, Wis. Admin. Code, or for a water supply system that is subject to a written advisory opinion by the DNR. For more information contact the DNR Section of Private Water Systems, P.O. Box 7921, Madison, WI 53707, telephone (608) 266-3415.
- ➤ The system shall be provided with an in-line total dissolved solids (TDS) monitor, or other acceptable means, to warn the user when the system is not performing it's functions. Acceptable alternatives to an in-line TDS monitor include:
 - 1. terminating the discharge of treated water:
 - 2. sounding an alarm which is connected to acceptable power source;
 - 3. flashing a light connected to an acceptable power source;
 - 4. providing the user with an obvious, readily interpretable, indication of the system's ability to perform (e.g. decreasing the flow rate of treated water by 50% or more for systems making mechanical filtration claims;
 - 5. Providing a sampling service by the manufacturer, either directly or through an authorized dealer, a minimum of once every six months;
 - 6. Providing a sampling kit for analysis of TDS or other appropriate contaminants; or
 - 7. Providing a TDS monitor to measure the product water quality.

Whichever means of performance verification is selected, it shall be clearly described in the owner's manual for this device, and approved for use along with the device.

SBD-10564-E (N.10/97) File Ref: 08018401.DOC

Kinetico November 18, 2008 Page 2 of 4

Product File No.: 20080184

- ➤ If this approved device is modified or additional assertions of function or performance are made, then this approval shall be considered null and void, unless the change is submitted to the department for review and the approval is reaffirmed.
- These devices will only reduce the concentration of cysts/oocysts at water outlets that are served by the devices. Therefore, using point-of-use devices such as these will not protect all routes of potential exposure. Potentially hazardous exposures to cysts/oocysts will remain possible at unprotected outlets.

The presence of cysts/oocysts strongly suggests that other pathogens (e.g. bacteria, virus) may also be present.

- If, by way of reputable water analyses, a water supply is known to contain cysts/oocysts, then all the water entering the residence must be treated at the point-of-entry, using an approved water treatment device, to address all potential routes of exposure thereby providing a biologically safe water supply.
- In addition to the product water quality monitor specified elsewhere in this letter, this device shall be provided with one of the following means to warn the user when the system is not performing its function:
 - 1. a nitrate/nitrite monitor on the product water stream; or
 - 2. a sampling and analysis kit for nitrate/nitrite with explicit instructions of recommended frequency of analysis.
- If the treatment components of this device (e.g. replacement cartridge) are replaced with anything other than those originally approved for use with this device, then this approval shall immediately be considered null and void.

Based on testing data submitted to and reviewed by the department, this approval recognizes that this plumbing product will reduce the concentration of contaminants as specified on pages 1 through 4 of this letter.

HEALTH EFFECTING INORGANIC CONTAMINANT REDUCTION CAPABILITIES PRODUCT FILE NUMBER 20080184 TABLE 1 OF 3

Product Water Production Rate: 77.2 liters per day (lpd) [20.4 gallons per day (gpd)]

Tested Contaminant	Tested Influent Concentration (mg/l)1
Arsenic (As ⁺⁵)	0.30 ± 10%
Asbestos Fibers (> 10 μm in length)	1.0 x 10 ⁷ to 1.0 x 10 ⁸ F/I
Barium (Ba ⁺²)	10.0 ± 10%
Cadmium (Cd ⁺²)	0.03 ± 10%
Copper (Cu ⁺²)	3.0 ± 10%
Hexavalent Chromium (Cr ⁺⁶)	0.15 ± 10%
Lead (Pb ⁺²)	0.15 ± 10%
Nitrate (NO ₃)	27.0 ± 10%
Nitrite (NO ₂ -)	3.0 ± 10%
Radium 226/228 (barium surrogate)	25 pCi/L
Selenium (Se ⁺⁴ and Se ⁺⁶)	0.10 ± 10%
Trivalent chromium (Cr ⁺³)	0.15 ± 10%

Other conditions: the contaminant reduction capabilities displayed for table 1 of 3 were generated by testing conducted in accordance with NSF/ANSI Standard 58. To qualify for arsenic reduction, the device must reduce the influent challenge concentrations such that all effluent concentrations are \leq 0.010 mg/l. To qualify for asbestos reduction, the device must reduce the influent challenge concentrations by \geq 99%. To qualify for barium reduction, the device must reduce the influent challenge water concentrations such that all

Kinetico November 18, 2008

Page 3 of 4 Product File No.: 20080184

(continued from previous page)

effluent concentrations are ≤ 2.0 mg/l. To qualify for cadmium reduction, the device must reduce the influent challenge concentrations such that all effluent concentrations are ≤ 0.005 mg/l. To qualify for copper reduction, the device must reduce the influent challenge water concentrations such that all effluent concentrations are ≤ 1.3 mg/l. To qualify for chromium reduction (i.e. trivalent or hexavalent), the device must reduce the influent challenge concentrations such that all effluent concentrations are ≤ 0.1 mg/l. To qualify for lead reduction, the device must reduce the influent challenge concentrations such that all effluent concentrations are ≤ 0.010 mg/l. To qualify for nitrate/nitrite reduction, the device must reduce the influent challenge water concentrations, such that all effluent concentrations are ≤ 10.0 mg/l (as N), also, no more than 1.0 mg/l (as N) shall be in the form of nitrite. To qualify for radium reduction, the device must reduce the influent barium challenge concentrations such that all effluent concentrations are ≤ 2.0 mg/l (barium is used as a surrogate based on its relationship with radium on the periodic table and the difficulty in using radium for routine testing). To qualify for selenium reduction, the device must reduce the influent challenge concentrations such that all effluent concentrations are ≤ 0.05 mg/l.

1 = milligrams per liter (mg/l) are equivalent to parts per million (ppm)

≤ = less than or equal to **F/I** = fibers per liter

μm = micrometers

 \pm = plus or minus

* = unless otherwise indicated

< = less than

≥ = greater than or equal to

HEALTH EFFECTING BIOLOGICAL CONTAMINANT REDUCTION CAPABILITIES PRODUCT FILE NUMBER 20080184 TABLE 2 OF 3

Product Water Production Rate: 77.2 liters per day (lpd) [20.4 gallons per day (gpd)]

Tested Contaminant	Influent Challenge (#/ml)
Cysts/Oocysts ¹	≥ 5.0 x 10 ⁴

Other Conditions: the contaminant reduction performance capabilities displayed for Table 2 of 3 were verified by testing conducted in accordance with NSF International Standard 58. To qualify for cyst/oocyst reduction, the device must reduce the influent challenge concentrations by ≥ 99.95% at each sample point.

1 = the specific organisms covered under this testing protocol include cryptosporidium parvum, entamoeba histolytica, giardia lamblia and toxoplasma gondii

≥ = greater than or equal to

#/ml = particles per milliliter

AESTHETIC INORGANIC CONTAMINANT REDUCTION CAPABILITIES PRODUCT FILE NUMBER 20080184 TABLE 3 OF 3

Product Water Production Rate: 77.2 liters per day (lpd) [20.4 gallons per day (gpd)]

Tested Contaminant	Average Influent Challenge (mg/l) ¹
Chlorine (free)	2.0 ± 10%
Total Dissolved Solids (NaCl surrogate)	750 ± 40

Other Conditions: the contaminant reduction performance capabilities displayed for Table 3 of 3 were verified by testing conducted in accordance with NSF International Standard 58. To qualify for free chlorine reduction, the device must reduce the influent challenge concentrations by ≥ 50%. To qualify for total dissolved solids (TDS) reduction, the device must reduce the influent challenge concentrations by ≥ 75%.

1 = milligrams per liter (mg/l) are equivalent to parts per million (ppm)

≥ = greater than or equal to

 \pm = plus or minus

Kinetico November 18, 2008 Page 4 of 4

Product File No.: 20080184

This device was tested under controlled laboratory, or field, conditions. The actual performance of this device for a specific end use installation will vary from the tested conditions based on local factors such as water pressure, water temperature and water chemistry.

The department is in no way endorsing this product or any advertising, and is not responsible for any situation which may result from its use.

Sincerely,

Glen W. Schlueter
Engineering Consultant-Plumbing Product Reviewer
Bureau of Integrated Services
Safety and Buildings Division
Department of Commerce
(608) 267-1401 Phone
(608) 267-9566 Fax
glen.schlueter@wi.gov Email
8:00AM – 4:30PM CT Work Hours
GWS:gws